



D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



1/5

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SARA 2F.OTM(OTM.2F)

M8X30



B1-8

M8X40



B2-2

M8



B3-2

M6X20




B4-8




B5-4



30 min



E1-4



E2-2



D1




C1-2




1



2



OTM.2F



1



1


2F.OTM



1



1



L2

1

L3

L4


2

L5

L6


1

1




L1

1




1

2F.OTM




OTM.2F





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



2/5

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SARA 2F.OTM(OTM.2F)

M8X30



B1-8

M8X40



B2-2

M8



B3-2

M6X20



B4-8




B5-4



E1-4




E2-2





D1



C1-2




1.




2F.OTM


OTM.2F




2.




2.



3.



3.





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



3/5

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SARA 2F.OTM(OTM.2F)

M8X30



B1-8

M8X40



B2-2

M8



B3-2

M6X20




B4-8



B5-4



E1-4



E2-2




D1





C1-2


2F.OTM






OTM.2F



OTM.2F






2F.OTM




2F.OTM

OTM.2F





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



4/5

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SARA 2F.OTM(OTM.2F)

M8X30



B1-8

M8X40



B2-2

M8




B3-2



M6X20




B4-8



B5-4




E1-4




h-100

E2-2




D1






C1-2

2F.OTM




OTM.2F





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
 PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
 RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
 SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



5/5

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SARA 2F.OTM(OTM.2F)

M8X30



B1-8

M8X40



B2-2

M8



B3-2


M6X20




B4-8




B5-4



E1-4














E2-2



D1



C1-2



Service-Dienstverlening-Serwis-Servis-Сервисная служба-Assistenza-Szerviz

B1		C1				
B2		L1				
B3		L2				
B4		L3				
B5		L4				
E1		L5				
E2		L6				
D1						

