


## linstallation steps:

- 1. Connect the controller with the lamps.
- 2. Connect power cable with controller.
- 3. Connect the USB power cable
- 4. Use the remote controller to change the colors modes; the signal light on the remote controller should be targeted to the signal receiver.



- A: Brightness + / Brightness -
- B: Static RGB colors
- C: DIY RGB colors
- D: Scenes lighting
- E: Music sync modes
- F: Timers
- G: ON/OFF
- H: Mix white
- I: Dynamic running color modes(9 options, changing by single press)
- J: Adjusting speed under dynamic running color modes