










INSTRUCTION SHEET

27930001/01






1




D x 12


2




A x 4



B x 4




C x 4




E x 4

3







4






E x 8

5



6



7

