




C18202MX / 82272143


Luca
BESSONI



OFF



Pairing mode: after power-on, long press the "O" button, until flickring




ON

DE: Leuchtmittel nicht austauschbar
HU: Izzó nem cserélhető
BG: Кръшката не се сменя
FR: Ampoule non remplaçable
IT: Sorgente luminosa non intercambiabile



DE: Austausch des Betriebsgeräts durch eine Fachkraft
HU: A kezelőeszköz cseréje szakember által
BG: Смяна на работещия апарат от специалист
FR: Remplacement du dispositif de commande par un spécialiste
IT: Sostituzione del dispositivo operativo da parte di uno specialista



MX Logistika SL, spol.s.r.o
ROZNAVSKA 32
SK-82104 BRATISLAVA
Slovakia
UID: SK2022467568
www.moebelix.com
info@moebelix.at

AC 220-240V~ 50/60Hz, max 50W
2402-2426MHz @ 7.55dBm



DE: Dieses Produkt enthält eine Lichtquelle der Energieeffizienzklasse: D
HU: A termék a következő energiaosztályba tartozó fényforrást tartalmaz: D
BG: Този продукт съдържа източник на светлина с клас на енергийна ефективност: D
FR : Ce produit contient une source lumineuse de classe d'efficacité énergétique: D
IT: Questo prodotto contiene una sorgente luminosa di classe di efficienza energetica: D