



L I Z A U S A R O K





GB: WARNING TO AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer - could be a rug.
IMPORTANT!

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

DK: ADVERSEL FOR AT FORHINDRE RIDSER!

For at forhindre ridser skal dette møbel samles på et blødt underlag, f.eks. et tæppe.
VIGTI GT!

Det er vigtigt, at alle produkter, der samles med alle former for skruer, efterspændes to uger efter samling samt hver tredje måned for at sikre, at produktet er stabilt i hele dets levetid.

PL: OSTRZEŻENI E WS. USZKODZEN!

Aby uniknąć rys, ten mebel powinien być montowany, składani na miękkim podłożu, np. dywanie.

WAŻNE!



Ważne jest, żeby każdy ze skręcanych produktów został ponownie dokręcony w ciągu 2 tygodni od montażu, a następnie sprawdzać co 3 miesiące czy śruby są dokręcone - w celu zapewnienia stabilności przez czas użytkowania produktu.

HU: KARCOLÁSOK MEGELŐZÉSE - FIGYELEM!


A karcolások megelőzése érdekében a bútort puha felületen, például szőnyegen kell összeszerelni.

FONTOS!

Minden terméknél fontos, hogy bármilyen fajta csavarral is történik az összeszerelés, utána két héttel, majd 3 havi rendszerességgel szükséges a csavarok utánhúúzása. Ezzel a termék teljes élettartalmán keresztül biztosítható a stabilitása.



8x



A

6x50

14x



B



5x70

14x








C


50x70




1.



2.



3.



4.

