









C22513MX / 82272066

Luca BESSONI



spare part		
Code code	part	amount
A		2
B		2



DE: Leuchtmittel nicht austauschbar

HU: Izzó nem cserélhető

BG: Крушката не се сменя

FR: Ampoule non remplaçable

IT: Sorgente luminosa non intercambiabile




DE: Austausch des Betriebsgeräts durch eine Fachkraft

HU: A kezelőeszköz cseréje szakember által

BG: Смяна на работещия апарат от специалист

FR: Remplacement du dispositif de commande par un spécialiste

IT: Sostituzione del dispositivo operativo da parte di uno specialista



AC 220-240V~ 50/60Hz, 36W



MX Logistika SL, spol.s.r.o

ROZNAVSKA 32

SK-82104 BRATISLAVA

Slovakia

UID: SK2022467568

www.moebelix.com

info@moebelix.at

DE: Dieses Produkt enthält eine Lichtquelle der Energieeffizienzklasse: E

HU: A termék a következő energiaosztályba tartozó fényforrást tartalmaz: E

BG: Този продукт съдържа източник на светлина с клас на енергийна ефективност: E

FR: Ce produit contient une source lumineuse de classe d'efficacité énergétique: E

IT: Questo prodotto contiene una sorgente luminosa di classe di efficienza energetica: E