













ASSEMBLY INSTRUCTION - 16940006 / 01






Ⓐ		x 4 pcs
Ⓑ		x 2 pcs
Ⓒ		x 2 pcs
Ⓓ		x 2 pcs
Ⓔ		x 2 pcs
Ⓕ		x 3 pcs
①	 M6x20	x 24 pcs
②	 ∅6x14	x 20 pcs
④	 4 x 60	x 1 pc


1




2









3





4







G		6 PCS
H		6 PCS
I		6 PCS
K		6 PCS
L		6 PCS

3	 M6 x 40	48 PCS
4	 Allenkey 4 x 60	1 PC


1




2



3



4



5

