

BDSK Handels GmbH & Co. KG


Mergentheimer Strasse 59

DE-97084 Würzburg

Germany

ASSEMBLING INSTRUCTION

26870345-02




Hardware:


Letter	Piece	Number	Letter	Piece	Number
A		12pcs	Ι	5x40mm	4pcs
В	15x12mm	12pcs	J		12sets
С	4x12mm	24pcs	K	6x40mm	4pcs
D		16pcs	L		2pcs
Е		4pcs	M	Onns	2sets
F	3x12mm	6pcs	N		1pc
G	6x12mm	4pcs	Р		1pc
Н	6x30mm	10pcs			


Using Cam Lock and Quickfit


QUICKFIT




CAM LOCK











Tools Required







CAUTION: Do not use tools other than those required, as this can damage your new item.

NOTE

- Please check you have all hardware before assembling.
- If you are missing any hardware, please contact the store of purchase.
- Please ensure you have the name of the item, required hardware part and quantity.
- Please retain your receipt as proof of purchase to validate your warranty.

CAUTION


- Do not tighten screws before all screws are in the right place.
- Do not use this product unless all bolts, screws and knobs are firmly secured.
- Check that all bolts, screws and knobs are securely tightened at least every 4 months.


WARNING


- If parts are missing, broken, damaged or worn stop using the product until all repairs are made using manufacturer authorised parts.
- Failure to follow these warnings could result in serious injury.


DANGER


CHILDREN MUST BE SUPERVISED.


























L

