











C17270MX / 82272002

Luca BESSONI



ACCESSORIES		
 4x	Included	✓
	Not included	
 4x	Included	✓
	Not included	
 4x	Included	✓
	Not included	
	Included	
	Not included	




DE: Leuchtmittel nicht austauschbar
HU: Izzó nem cserélhető
BG: Кръшката не се сменя
FR: Ampoule non remplaçable
IT: Sorgente luminosa non intercambiabile



AC 220-240V~ 50/60Hz, 30W



DE: Austausch des Betriebsgeräts durch eine Fachkraft
HU: A kezelőeszköz cseréje szakember által
BG: Смяна на работещия апарат от специалист
FR: Remplacement du dispositif de commande par un spécialiste
IT: Sostituzione del dispositivo operativo da parte di uno specialista



MX Logistika SL, spol.s.r.o
ROZNAVSKA 32
SK-82104 BRATISLAVA
Slovakia
UID: SK2022467568
www.moebelx.com
info@moebelx.at

DE: Dieses Produkt enthält eine Lichtquelle der Energieeffizienzklasse: F
HU: A termék a következő energiaosztályba tartozó fényforrást tartalmaz: F
BG: Този продукт съдържа източник на светлина с клас на енергийна ефективност: F
FR: Ce produit contient une source lumineuse de classe d'efficacité énergétique: F
IT: Questo prodotto contiene una sorgente luminosa di classe di efficienza energetica: F