




D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
 PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
 RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
 SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



1/2

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

RAFAEL SO2

M8X40



B1-6



B2-6

US 5X30



B3-4

5







D1-x1

H=25



E1-4





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
 PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
 RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
 SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



2/2

Name-Naam-Nazwa-Isim-Название-Ном-Номе-Нázov-Név

RAFAEL SO2

M8X40



B1-6



B2-6

US 5X30



B3-4

5












D1 -x1

H=25



E1-4



Service-Dienstverlening-Serwis-Servis-Сервисная служба-Assistenza-Szerviz

L1		B1				
L2		B2				
L3		B3				
		E1				
		D1				

