

BDSK Handels GmbH & Co. KG


Mergentheimer Strasse 59

DE-97084 Würzburg

Germany

ASSEMBLING INSTRUCTION

26870345-04




Hardware:


Letter	Piece	Number	Letter	Piece	Number
A	6x35mm	28pcs	J		4pcs
В	8x30mm	16pcs	K	Symmen	2pcs
С	15x12mm	12pcs	L	Onns Onns	1set
D	Symmotion 5x40mm	4pcs	M		1pc
Е	⊚panaman 6x30mm	6pcs	N	Om Com	8pcs
F	⊚ 6x12mm	4pcs	Р	(a)	8sets
G	3x12mm	32pcs	Q	15x9.5mm	16pcs
Н	With the 4x30mm	16pcs	R	Grand 6x40mm	4pcs
I		8pcs			


Using Cam Lock and Quickfit


QUICKFIT




CAM LOCK











Tools Required







CAUTION: Do not use tools other than those required, as this can damage your new item.

NOTE

- Please check you have all hardware before assembling.
- If you are missing any hardware, please contact the store of purchase.
- Please ensure you have the name of the item, required hardware part and quantity.
- Please retain your receipt as proof of purchase to validate your warranty.

CAUTION

- Do not tighten screws before all screws are in the right place.
- Do not use this product unless all bolts, screws and knobs are firmly secured.
- Check that all bolts, screws and knobs are securely tightened at least every 4 months.

WARNING

- If parts are missing, broken, damaged or worn stop using the product until all repairs are made using manufacturer authorised parts.
- Failure to follow these warnings could result in serious injury.

DANGER

CHILDREN MUST BE SUPERVISED.

