



# The Sway Rainbow Ramp

## ASSEMBLY INSTRUCTIONS

### HARDWARE LIST



### COMPONENT LIST



### WARNING




Adult assembly required. Product includes small parts with potentially hazardous sharp points and sharp edges in the unassembled state. Keep unassembled parts away from children.

### Helpful Advice

1. Follow the assembly instructions carefully.
2. Check to ensure all parts, fasteners and hardware are present and in good order.
3. Clean surface of furniture with a duster or damp cloth only. Do not use abrasive cleaners. Scuff Marks may be removed with a soft damp cloth and small amount of Gumption (can be purchased from local supermarket)

# The Sway Rainbow Ramp

## ASSEMBLY INSTRUCTIONS



Ensure all screws and hardware are tightened and locked into place before use.  
Use only on a firm ground which is horizontal, level and dry.