










ASSEMBLY INSTRUCTION

16940088-01







A		1 PC x 2
B		1 PC x 2
C		1 PC x 2
D		1 PC x 2
L		1 PC x 2
M		1 PC x 2
N		1 PC x 2

1	 M6 x 70	4 PCS x 2
2	 M6 x 25	10 PCS x 2
3	 Ø6 x 14	14 PCS x 2
4	 M6 x 55	4 PCS x 2
5		4 PCS x 2
6	 Allenkey 4 x 25 x 98	1 PC


1




2











3





4







A		1 PC
B		1 PC
Q		1 PC
S		1 PC
U		1 PC
Z		1 PC
N		2 PCS

1	 M6 x 70	4 PCS
2	 M6 x 25	10 PCS
3	 Ø6 x 14	14 PCS
4	 M6 x 55	4 PCS
5		4 PCS
6	 Allenkey 4 x 25 x 98	1 PC


1




2






3





4







E		2 PCS
F		1 PC
G		1 PC

2	 M6 x 25	8 PCS
3	 Ø6 x 14	8 PCS
4	 M6 x 55	4 PCS
5		4 PCS
6	 Allenkey 4 x 25 x 98	1 PC

1



2



3

