



C14720MX / 82271510


Luca
BESSONI



Spare parts		
code	part	item no.
A	2x 	
B		
C	2x 	



DE: Leuchtmittel nicht austauschbar
HU: Izzó nem cserélhető
BG: Кръшката не се сменя
FR: Ampoule non remplaçable
IT: Sorgente luminosa non intercambiabile



DE: Betriebsgerät nicht austauschbar.
HU: Működtető eszköz nem cserélhető
BG: Пусково-регулирущата апаратура не се сменя
FR: Appareillage de commande non remplaçable
IT: Unità di alimentazione non intercambiabile

LED 20W
220-240V ~ 50/60Hz

DE: Dieses Produkt enthält eine Lichtquelle der Energieeffizienzklasse: D
HU: A termék a következő energiaosztályba tartozó fényforrást tartalmaz: D
BG: Този продукт съдържа източник на светлина с клас на енергийна ефективност: D
FR : Ce produit contient une source lumineuse de classe d'efficacité énergétique : D
IT: Questo prodotto contiene una sorgente luminosa di classe di efficienza energetica: D

