









23810368-01

 ①	 ②	 ③	 ④	 ⑤	 ⑥	
 ⑦	 5PCS ⑧	 ⑨	 ⑩	 ⑪	 ⑫	 ⑬
 2PCS ⑭	 M8*20 12PCS A	 M8*25 4PCS B	 M5*8 4PCS C	 4PCS D	 M6 E	



A line drawing of a hand saw. The blade is shown with a curved back and a pointed tip. A dashed line labeled 'A' points to the teeth of the blade. A dashed line labeled '4' points to the handle of the saw. A dashed line labeled '2' points to the back of the blade. An arrow labeled 'Front' points towards the left side of the blade.

This diagram shows the front panel assembly in an exploded view. The main front panel (1) is shown with two rectangular cutouts at the bottom. Above it is a horizontal support rail (2) with a central adjustment knob. To the left is a vertical support bracket (9) with a circular base. To the right is a vertical support bracket (10) with a circular base. Dashed lines labeled 'A' indicate the alignment and assembly points for the front panel (1) with the support rail (2) and the vertical brackets (9 and 10).





Pls lock the pallet when using the angel
adjust machine