

A*5	H*(R&L)1
B*1	I*4
C*1	J*4
D*1	K*6
E*1	L*1
F*1	
G*1	

1



2



3

4

5

6





For domestic use only. (EN)
Nur für den Haushaltsgebrauch. (DE)
Pouze pro používání v domácnosti. (CZ)
Endast för hushållsbruk. (SE)
Len na používanie v domácnosti. (SK)
Samo za domačo uporabo. (SI)
Kizárólag háztartási használatra alkalmas. (HU)
Samo za korištenje u kućanstvu. (HR)
Само за домашна употреба. (BGR)
Doar pentru uz casnic. (RO)
Réserve à un usage domestique uniquement. (FR)
Tylko do użytku domowego. (PL)
Prodotto destinato al solo uso domestico. (IT)
Isključivo za upotrebu u domaćinstvu. (RS)