
























INSTRUCTION SHEET

22240011-03




 ax28	 bx28	 cx24	 dx6	 ex48	 fx8	 gx24	 hx4
 ix6	 jx2	 kx4	 lx4	 mx8	 nx2	 ox2	 px2
 qx2	 rx8						


Step 1




Step 2




Step 3



Step 4







Step 5





 ax12	 bx12	 cx16
---	---	---

Step 6






 ax6	 bx6	 cx6
--	--	--


Step 7





Step 8



Step 9



Step 10



Step 11

